

Brunswick SSD Drill Template & Instructions

1. If printing this instruction template. Make sure to print at 100%, 1-1 scale, using the portrait setting.
2. Cut out the SSD Drill Template.
3. Tape the Drill Template on your IDE hard drive plate with the plug end of the template facing the flat end of the drive plate.
4. Drill holes through the two marked locations using a #4mm (1/8") drill bit. **Do not drill through the Microsoft license.**
5. Remove the drill template from the hard drive plate and attach your new SSD hard drive to the plate using the provided screws.



