

## **StringPin Pinsetter Pit Board Carpet Replacement**

### **Materials Required**

55-273500-000	Fiber Bonded Carpet (1m x 1.5m) - One per lane
55-273501-000	Glue Bucket (7 kg per bucket) - Each bucket will do 12 lanes.
55-273502-000	Notch Trowel for Glue

### **Instructions**

1. Remove the current material from the pit board (top material, staples, tacks, etc.).
2. Clean all dust and debris from the pit board.
3. Trim the carpet to the final dimensions (it will be oversized when you get it).
4. Apply the glue to the board surface using the notched trowel.
5. Allow the glue to set up, following the instructions on the glue container.
6. Apply the carpet without bubbles or bumps, smoothing by hand or roller.
7. Place two cases of bowling pins on the carpet to weigh it down while the glue sets.
8. It is okay to use staples or tacks to add extra hold to the edges along the front (pin deck side) and sides of the carpet. Staples and tacks should be avoided along the rear edge of the board as it could interfere with pin and ball transfer.