

# SERVICE BULLETIN


**Subject: New Product - Lane Step Gauge**

**Date: 8/22/11**

**Bulletin No. SB11-7**

The step gauge is used to measure the height difference between lane panels going down the lane and also between the approach panels. This is important to verify that as you go down the lane, each panel has the industry required step down to the next panel. It will also ensure that you have not exceeded the industry specifications with too much step down or even worse, a step up to the next panel. This tool is useful in checking for smooth steps from panel to panel on the approach in the slide and fill areas as well.

Order the Lane Step Gauge using package number 52-860334-000. The package includes a carrying case and the step gauge.



*Figure 1*

If you have questions regarding the information contained in this Service Bulletin, please contact Brunswick Technical Support at 1-800-937-2695 or 231-725-4966, FAX 231-725-4667, or Email [techsupport@brunbowl.com](mailto:techsupport@brunbowl.com) Visit <http://www.brunswickbowling.com/service-support/tech-support/> for electronic files of this and other Service Bulletins.

*Kord L. Daniels*  
Kord L. Daniels  
Service Product Engineer

*David E. Rice*  
David E. Rice  
Director of World Wide Service